

IN CASE OF FIRE





CONFINE FIRE AND SMOKE CLOSE DOORS AND WINDOWS (IF SAFE TO DO SO)

EVACUATE TO THE ASSEMBLY AREA

EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL 1300 323 753 www.fcfnational.com.au fireevacdiagrams.fcfnational.com.au DATE OF INSTALLATION: OCTOBER 2022

REVIEW DATE: OCTOBER 2027





DESIGNATED EXIT **SECONDARY ROUTE**




LEGEND

ASSEMBLY AREA









IN CASE OF FIRE





CONFINE FIRE AND SMOKE CLOSE DOORS AND WINDOWS (IF SAFE TO DO SO)

ADVISE FIRE WARDEN OF LOCATION

EVACUATE TO THE ASSEMBLY AREA

EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL 1300 323 753 www.fcfnational.com.au fireevacdiagrams.fcfnational.com.au DATE OF INSTALLATION: OCTOBER 2022

REVIEW DATE: OCTOBER 2027



DESIGNATED EXIT **SECONDARY ROUTE**




PRIMARY ASSEMBLY AREA







EVACUATION DIAGRAM



IN CASE OF FIRE





ALERT FIRE SERVICE

CALL 000

BREAK MANUAL CALL POINT
ADVISE FIRE WARDEN OF LOCATION



CONFINE FIRE AND SMOKE CLOSE DOORS AND WINDOWS (IF SAFE TO DO SO)

EVACUATE

TO THE ASSEMBLY AREA

EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate Danger Area

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL
1300 323 753
www.fcfnational.com.au
fireevacdiagrams.fcfnational.com.au
DATE OF INSTALLATION:
OCTOBER 2022
REVIEW DATE: OCTOBER 2027

LEGEND

DIAGRAM COMPLIES WITH THE MINIMUM ELEMENTS OF SECTION 3.5.5 OF AS3745:2010

SITE MAP
















EVACUATION DIAGRAM



IN CASE OF FIRE







ADVISE FIRE WARDEN OF LOCATION



EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate Danger Area

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL
1300 323 753
www.fcfnational.com.au
fireevacdiagrams.fcfnational.com.au
DATE OF INSTALLATION:
OCTOBER 2022

REVIEW DATE: OCTOBER 2027






SECONDARY ROUTE DESIGNATED EXIT











IN CASE OF FIRE

REMOVE PEOPLE FROM IMMEDIATE DANGER



BREAK MANUAL CALL POINT ADVISE FIRE WARDEN OF LOCATION

CONFINE FIRE AND SMOKE CLOSE DOORS AND WINDOWS (IF SAFE TO DO SO)

EVACUATE TO THE ASSEMBLY AREA

EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL 1300 323 753 www.fcfnational.com.au fireevacdiagrams.fcfnational.com.au DATE OF INSTALLATION: OCTOBER 2022

REVIEW DATE: OCTOBER 2027






























DRUM THEATRE

226 Lonsdale Street, Dandenong VIC 3175 **GROUND FLOOR**







IN CASE OF FIRE





BREAK MANUAL CALL POINT ADVISE FIRE WARDEN OF LOCATION

CONFINE FIRE AND SMOKE CLOSE DOORS AND WINDOWS (IF SAFE TO DO SO)



EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL 1300 323 753 www.fcfnational.com.au fireevacdiagrams.fcfnational.com.au DATE OF INSTALLATION: OCTOBER 2022 **REVIEW DATE: OCTOBER 2027**

LEGEND
































FIP

DRUM THEATRE

226 Lonsdale Street, Dandenong VIC 3175

GROUND FLOOR



IN CASE OF FIRE





CALL 000 BREAK MANUAL CALL POINT

ADVISE FIRE WARDEN OF LOCATION

CONFINE FIRE AND SMOKE CLOSE DOORS AND WINDOWS (IF SAFE TO DO SO)

EVACUATE TO THE ASSEMBLY AREA

EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate Danger Area

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL 1300 323 753 www.fcfnational.com.au fireevacdiagrams.fcfnational.com.au DATE OF INSTALLATION: OCTOBER 2022 **REVIEW DATE: OCTOBER 2027**

LEGEND

DIAGRAM COMPLIES WITH THE MINIMUM ELEMENTS OF SECTION 3.5.5 OF AS3745:2010



WALKER STREET



LONSDALE STREET

LANGHORNESTREE



SITE MAP















Mathew Smallwood Consulting

Emergency Management, Security & Safety Specialist








DRUM THEATRE

226 Lonsdale Street, Dandenong VIC 3175 **GROUND FLOOR**







IN CASE OF FIRE





BREAK MANUAL CALL POINT ADVISE FIRE WARDEN OF LOCATION





EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL 1300 323 753 www.fcfnational.com.au fireevacdiagrams.fcfnational.com.au DATE OF INSTALLATION: OCTOBER 2022 **REVIEW DATE: OCTOBER 2027**

LEGEND






























IN CASE OF FIRE

REMOVE PEOPLE FROM IMMEDIATE DANGER



CONFINE FIRE AND SMOKE CLOSE DOORS AND WINDOWS (IF SAFE TO DO SO)

ADVISE FIRE WARDEN OF LOCATION

EVACUATE TO THE ASSEMBLY AREA

EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL 1300 323 753 www.fcfnational.com.au fireevacdiagrams.fcfnational.com.au DATE OF INSTALLATION: OCTOBER 2022 **REVIEW DATE: OCTOBER 2027**

LEGEND


































IN CASE OF FIRE

REMOVE PEOPLE FROM IMMEDIATE DANGER



BREAK MANUAL CALL POINT
ADVISE FIRE WARDEN OF LOCATION

CONFINE FIRE AND SMOKE
CLOSE DOORS AND WINDOWS
(IF SAFE TO DO SO)

EVACUATE
TO THE ASSEMBLY AREA

EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate Danger Area

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL
1300 323 753
www.fcfnational.com.au
fireevacdiagrams.fcfnational.com.au
DATE OF INSTALLATION:
OCTOBER 2022

LEGEND




























EVACUATION DIAGRAM



IN CASE OF FIRE





CALL 000

BREAK MANUAL CALL POINT

ADVISE FIRE WARDEN OF LOCATION

CONFINE FIRE AND SMOKE
CLOSE DOORS AND WINDOWS
(IF SAFE TO DO SO)

EVACUATE
TO THE ASSEMBLY AREA

EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate Danger Area

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL
1300 323 753
www.fcfnational.com.au
fireevacdiagrams.fcfnational.com.au
DATE OF INSTALLATION:
OCTOBER 2022
REVIEW DATE: OCTOBER 2027

LEGEND

DIAGRAM COMPLIES WITH THE MINIMUM ELEMENTS OF SECTION 3.5.5 OF AS3745:2010
























Emergency Management, Security & Safety Specialist







EVACUATION DIAGRAM





IN CASE OF FIRE





CONFINE FIRE AND SMOKE
CLOSE DOORS AND WINDOWS
(IF SAFE TO DO SO)

ADVISE FIRE WARDEN OF LOCATION



EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate Danger Area

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL
1300 323 753
www.fcfnational.com.au
fireevacdiagrams.fcfnational.com.au
DATE OF INSTALLATION:
OCTOBER 2022
REVIEW DATE: OCTOBER 2027






















SITE MAP

EVACUATION DIAGRAM

DRUM THEATRE

226 Lonsdale Street, Dandenong VIC 3175 LEVEL 2





IN CASE OF FIRE





ADVISE FIRE WARDEN OF LOCATION

CONFINE FIRE AND SMOKE
CLOSE DOORS AND WINDOWS
(IF SAFE TO DO SO)

EVACUATE
TO THE ASSEMBLY AREA

EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate Danger Area

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL
1300 323 753
www.fcfnational.com.au
fireevacdiagrams.fcfnational.com.au
DATE OF INSTALLATION:
OCTOBER 2022
REVIEW DATE: OCTOBER 2027

LEGEND





LONSDALE STREET







PRIMARY ASSEMBLY AREA










LONSDALE STREET

EVACUATION DIAGRAM

DRUM THEATRE

226 Lonsdale Street, Dandenong VIC 3175 LEVEL 2





IN CASE OF FIRE





BREAK MANUAL CALL POINT

ADVISE FIRE WARDEN OF LOCATION



EVACUATETO THE ASSEMBLY AREA

EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate Danger Area

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL
1300 323 753
www.fcfnational.com.au
fireevacdiagrams.fcfnational.com.au
DATE OF INSTALLATION:
OCTOBER 2022
REVIEW DATE: OCTOBER 2027

LEGEND

DIAGRAM COMPLIES WITH THE MINIMUM ELEMENTS OF SECTION 3.5.5 OF AS3745:2010









PRIMARY ASSEMBLY AREA












226 Lonsdale Street, Dandenong VIC 3175

LEVEL 2

SITE MAP



IN CASE OF FIRE





BREAK MANUAL CALL POINT ADVISE FIRE WARDEN OF LOCATION **CONFINE FIRE AND SMOKE**

CLOSE DOORS AND WINDOWS (IF SAFE TO DO SO)

EVACUATE TO THE ASSEMBLY AREA

EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL 1300 323 753 www.fcfnational.com.au fireevacdiagrams.fcfnational.com.au DATE OF INSTALLATION: OCTOBER 2022 **REVIEW DATE: OCTOBER 2027**

LEGEND

DIAGRAM COMPLIES WITH THE MINIMUM ELEMENTS OF SECTION 3.5.5 OF AS3745:2010



LONSDALE STREET

LANGHORNESTREET







PRIMARY ASSEMBLY AREA



SECONDARY ASSEMBLY AREA



Mathew Smallwood Consulting

Emergency Management, Security & Safety Specialist






DRUM THEATRE

226 Lonsdale Street, Dandenong VIC 3175

LEVEL 2

SITE MAP



IN CASE OF FIRE





ADVISE FIRE WARDEN OF LOCATION **CONFINE FIRE AND SMOKE**

CLOSE DOORS AND WINDOWS (IF SAFE TO DO SO)

EVACUATE TO THE ASSEMBLY AREA

EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL 1300 323 753 www.fcfnational.com.au reevacdiagrams.fcfnational.com.au DATE OF INSTALLATION: OCTOBER 2022 **REVIEW DATE: OCTOBER 2027**

LEGEND

DIAGRAM COMPLIES WITH THE MINIMUM ELEMENTS OF SECTION 3.5.5 OF AS3745:2010



LANGHORNE STREET

LONSDALESTREET



WALKER STREET





PRIMARY ASSEMBLY AREA



SECONDARY **ASSEMBLY AREA**




Mathew Smallwood Consulting

Emergency Management, Security & Safety Specialist





EVACUATION DIAGRAM



IN CASE OF FIRE

REMOVE PEOPLE FROM IMMEDIATE DANGER



BREAK MANUAL CALL POINT
ADVISE FIRE WARDEN OF LOCATION

CONFINE FIRE AND SMOKE

CLOSE DOORS AND WINDOWS (IF SAFE TO DO SO)

EVACUATE

TO THE ASSEMBLY AREA

EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate Danger Area

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL
1300 323 753
www.fcfnational.com.au
fireevacdiagrams.fcfnational.com.au
DATE OF INSTALLATION:
OCTOBER 2022
REVIEW DATE: OCTOBER 2027

LEGEND

DIAGRAM COMPLIES WITH THE MINIMUM ELEMENTS OF SECTION 3.5.5 OF AS3745:2010









PRIMARY
ASSEMBLY AREA










EVACUATION DIAGRAM



IN CASE OF FIRE





BREAK MANUAL CALL POINT

ADVISE FIRE WARDEN OF LOCATION



EVACUATETO THE ASSEMBLY AREA

EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate Danger Area

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL
1300 323 753
www.fcfnational.com.au
fireevacdiagrams.fcfnational.com.au
DATE OF INSTALLATION:
OCTOBER 2022
REVIEW DATE: OCTOBER 2027

LEGEND


















EVACUATION DIAGRAM



IN CASE OF FIRE





ADVISE FIRE WARDEN OF LOCATION

CONFINE FIRE AND SMOKE

CLOSE DOORS AND WINDOWS



(IF SAFE TO DO SO)

EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate Danger Area

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL
1300 323 753
www.fcfnational.com.au
fireevacdiagrams.fcfnational.com.au
DATE OF INSTALLATION:
OCTOBER 2022
REVIEW DATE: OCTOBER 2027

LEGEND






















SITE MAP

EVACUATION DIAGRAM

DRUM THEATRE

226 Lonsdale Street, Dandenong VIC 3175 UPPER LEVEL 1





IN CASE OF FIRE





CALL 000

BREAK MANUAL CALL POINT

ADVISE FIRE WARDEN OF LOCATION





EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate Danger Area

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL
1300 323 753
www.fcfnational.com.au
fireevacdiagrams.fcfnational.com.au
DATE OF INSTALLATION:
OCTOBER 2022
REVIEW DATE: OCTOBER 2027

LEGEND

DIAGRAM COMPLIES WITH THE MINIMUM ELEMENTS OF SECTION 3.5.5 OF AS3745:2010



WALKER STREET

LANGHORNE STREET







PRIMARY ASSEMBLY AREA










EVACUATION DIAGRAM

DRUM THEATRE

226 Lonsdale Street, Dandenong VIC 3175 UPPER LEVEL 1





IN CASE OF FIRE







ADVISE FIRE WARDEN OF LOCATION



EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate Danger Area

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL
1300 323 753
www.fcfnational.com.au
fireevacdiagrams.fcfnational.com.au
DATE OF INSTALLATION:
OCTOBER 2022
REVIEW DATE: OCTOBER 2027

LEGEND

DIAGRAM COMPLIES WITH THE MINIMUM ELEMENTS OF SECTION 3.5.5 OF AS3745:2010



WALKER STREET

<u>"111"</u>

ANGHORNE



SITE MAP





PRIMARY ASSEMBLY AREA












WALKER STREET

EVACUATION DIAGRAM

DRUM THEATRE


226 Lonsdale Street, Dandenong VIC 3175 GRID AND UPPER PLANT 2



IN CASE OF FIRE







CONFINE FIRE AND SMOKE



EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate Danger Area

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex

Should the emergency necessitate evacuation of the whole building, the Manager or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL.

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to FIRE OFFICERS.



Mobility Impaired persons should evacuate Immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL 1300 323 753 www.fcfnational.com.au fireevacdiagrams.fcfnational.com.au DATE OF INSTALLATION: OCTOBER 2022 **REVIEW DATE: OCTOBER 2027**

LEGEND

DIAGRAM COMPLIES WITH THE MINIMUM ELEMENTS OF SECTION 3.5.5 OF AS3745:2010



SITE MAP

LANGHORNE STREET









